


Repairing Salmon trigger litter pickers with internal string/cord.

These instructions apply to the Hillbrush Salmon Picker with Trigger Guard as illustrated. The only problem that tends to happen is that the cord, which is just wrapped around the top of the moving jaw part and loosely knotted, slips or the cord stretches, meaning that the jaw will not close properly.



To repair, clamp the jaws loosely in a vice or get somebody to hold them closed and then tie a knot in the cord as in the third photo.

The Helping Hand Company LP1133IB Litter Picker is similar but without a trigger guard



The same instructions should work as it suffers a similar problem.

© Instructions copyright Graham Hadfield 2022. These instructions may be freely used and shared by anyone but please include this notice.